时序空间端点匹配算法 Kylin

目录

Step1. 数据读取与设置

Step2. 判断长度端点分布构型

- 1.判断左右或上下点分布构型
- 2.根据点分布构型进行数据写入
- 3.不同相机相同点的数据整理工作

Step3. 绘图检查匹配结果

封装函数备用行

% function[Ruler_Observe_match] = MainRulerMatch(CamRuler,CamNum,RulerNum)

Step1. 数据读取与设置

```
clc;clear;close all;
CamRuler{1}=load('C:\Users\Kylin\Desktop\On-site
measurement\OnsiteALLtest_1\picset\Cam1_Ruler\pointStructure.mat');
CamRuler{2}=load('C:\Users\Kylin\Desktop\On-site
measurement\OnsiteALLtest_1\picset\Cam2_Ruler\pointStructure.mat');
CamRuler{3}=load('C:\Users\Kylin\Desktop\On-site
measurement\OnsiteALLtest_1\picset\Cam3_Ruler\pointStructure.mat');
CamRuler{4}=load('C:\Users\Kylin\Desktop\On-site
measurement\OnsiteALLtest_1\picset\Cam4_Ruler\pointStructure.mat');
CamNum=4;
RulerNum=4;
PointDistribution=0;%状态判断变量
```

Step2. 判断长度端点分布构型

1.判断左右或上下点分布构型

Step2 整体为双层循环结构: 首先处理同一个空间长度在不同相机像面中的点分类, 再以空间长度为顺序进行遍历处理

```
for RulerOrder=1:RulerNum%

for CamOrder=1:CamNum

Rulerpoint=CamRuler{1, CamOrder}.pointStructure(RulerOrder).point;
Rulerpoint_DeltX=abs(Rulerpoint(1,2)-Rulerpoint(2,2));%两端点坐标 xy 相减
取绝对值判断是上下构型还是左右构型
```

```
Rulerpoint_DeltY=abs(Rulerpoint(1,3)-Rulerpoint(2,3));
    if Rulerpoint DeltX>Rulerpoint DeltY %左右构型
        PointDistribution=1;%左右分布
            if Rulerpoint(1,2)<Rulerpoint(2,2)</pre>
                    left point(CamOrder,:)=Rulerpoint(1,2:4);
                    right_point(CamOrder,:)=Rulerpoint(2,2:4);
            else
                    right_point(CamOrder,:)=Rulerpoint(1,2:4);
                    left_point(CamOrder,:)=Rulerpoint(2,2:4);
            end
    else%上下构型
        PointDistribution=2;%上下分布
            if Rulerpoint(1,3)<Rulerpoint(2,3)</pre>
                    up_point(CamOrder,:)=Rulerpoint(2,2:4);
                    down_point(CamOrder,:)=Rulerpoint(1,2:4);
            else
                    down_point(CamOrder,:)=Rulerpoint(2,2:4);
                    up_point(CamOrder,:)=Rulerpoint(1,2:4);
            end
    end
end
```

2.根据点分布构型进行数据写入

```
if PointDistribution==1%左右分布
    left_point(:,3)=2*RulerOrder-1;
    right_point(:,3)=2*RulerOrder;

else%上下分布
    up_point(:,3)=2*RulerOrder-1;
    down_point(:,3)=2*RulerOrder;
```

3.不同相机相同点的数据整理工作

```
for CamOrder=1:CamNum %不同相机相同点的整理工作
```

```
if PointDistribution==1%左右分布

Ruler_Observe_match{CamOrder}(2*RulerOrder-1,:)=left_point(CamOrder,:);
Ruler_Observe_match{CamOrder}(2*RulerOrder,:)=right_point(CamOrder,:);
else

Ruler_Observe_match{CamOrder}(2*RulerOrder-1,:)=up_point(CamOrder,:);
Ruler_Observe_match{CamOrder}(2*RulerOrder,:)=down_point(CamOrder,:);
end
end
end
```

Step3. 绘图检查匹配结果

```
for i=1:CamNum
    figure(i)
plot(Ruler_Observe_match{i}(:,1),Ruler_Observe_match{i}(:,2),'bo');
text(Ruler_Observe_match{i}(:,1)+0.2,Ruler_Observe_match{i}(:,2)-
0.2,[num2str(Ruler_Observe_match{i}(:,3))],'FontSize',15)
xlim([-8 8]);
ylim([-8 8]);
grid on
legend("Ruler points")
title(['Cam',num2str(i)])
xlabel("x(mm)")
ylabel("y(mm)")
end
```



